



ZYXEL VMG VE VIGOR ROUTER ARASINDA IPSEC VPN

Bu uygulama notu, Vigor router ve Zyxel VMG router arasında nasıl IPsec VPN tüneli kurulacağını göstermektedir. Vigor Router'ın 192.168.24.0/24 IP adresinde LAN alt ağına sahip olduğunu ve Zyxel VMG'nin 192.168.1.0/24 adresinde olduğunu varsayalım.

Vigor Router Ayarları

1. VPN and Remote Access >> IPsec General Setup sayfasına gidin ve Pre-Shared Key girin.

VPN and Remote Access >> IPsec Genera	l Setup	
VPN IKE/IPsec General Setup		
Dial-in Set up for Remote Dial-in users	and Dynamic IP Client (LAN to LAN).	
IKE Authentication Method		
Pre-Shared Key	•••••	
Confirm Pre-Shared Key	•••••	
IPsec Security Method		
🗹 Medium (AH)		
Data will be authentic, but v	vill not be encrypted.	
High (ESP) 🛛 DES 💟 3DI	ES 🛃 AES	
Data will be encrypted and a	authentic.	

- 2. VPN and Remote Access >> LAN to LAN sayfasına gidin ve uygun bir indexe tıklayın,
 - Profile name girin.
 - Enable this profile'1 etkinleştirin.
 - Call Diection için "Dial-in" seçeneğini seçin.

Allowed Dial-In Type		Username	???
PPTP IPsec Tunnel I 2TP with IPsec Polic	V None	Password(Max 11 char VJ Compression	r) • On () Off
Specify Remote VPN (Peer VPN Server IP	Gateway	IKE Authentication Met Pre-Shared Key IKE Pre-Shared Key Dipital Signature(X	hod
or Peer ID		None ≎ Local ID ⊙Alternative Sub	ject Name First First
		IPsec Security Method ⊘ Medium(AH) High(ESP) ⊘ DES	☑ 3DES ☑ AES
4. TCP/IP Network Settings	•		
My WAN IP Remote Gateway IP	0.0.0.0	RIP Direction From first subnet to re	Disable ᅌ emote network, you have to
Remote Network IP Remote Network Mask	192.168.24.1 255.255.255.0	Change default rou	Route 📀
Local Network Mask	255.255.255.0	single WAN supports t	his)

- Dial-in Settings'de **IPsec Tunnel** izin verin.
- TCP/IP Network Settings > Remote Network IP/Mask'da VMG Router'ın LAN'ını girin.





3. Dial-In Settings

Allowed Dial-In Type		Username	???]
PPTP IPsec Tunnel	V None 🗘	Password(Max 11 char) VJ Compression	• On 🔾 Off	
Specify Remote VPN	Gateway	IKE Authentication Method ✓ Pre-Shared Key IKE Pre-Shared Key Digital Signature(X.50 None ≎ Local ID ● Alternative Subject Subject Name Firs IPsec Security Method ✓ Medium(AH) High(ESP) ✓ ØES ✓	9) t Name First t	
4. TCP/IP Network Settings	;			_
My WAN IP Remote Gateway IP	0.0.0.0	RIP Direction From first subnet to remo	Disable ᅌ Dise network, you have to	
Remote Network IP Remote Network Mask Local Notwork IP	192.168.24.1 255.255.255.0 192.168.1.1	Change default route	Route 📀	
Local Network Mask	255.255.255.0 More	single WAN supports this)	

Zyxel VMG Router Ayarları

- 1. IPsec VPN Setup sayfasına gidin ve Add New Connection'a tıklayın.
 - Active'i işaretleyin.
 - IPsec Connection Name girin.
 - Remote IPsec Gateway Address'de Vigor Router'ın WAN IP'si ya da Domainini girin.
 - Tunnel access from local IP addresses için Subnet'i seçin ve Vigor Router'ın LAN'ını girin.
 - **Pre-Shared Key** girin.

IF

SEC VPN Add	
✓Active	
IPSec Connection Name	client
Remote IPSec Gateway Address (IP or Domain	vigor.vpnserver.net
Name)	
Tunnel access from local IP addresses	Subnet ᅌ
IP Address for VPN	192.168.24.1
IP Subnetmask	255.255.255.0
Tunnel access from remote IP addresses	Subnet ᅌ
IP Address for VPN	192.168.1.1
IP Subnetmask	255.255.255.0
Protocol	ESP ᅌ
Key Exchange Method	Auto(IKE)
Authentication Method	Pre-Shared Key
Pre-Shared Key	presharedkey





- 2. IKE Advanced Settings'de more'a tıklayın.
 - Mode için "Main" i seçin.
 - Phase 1 Encryption Algorithm'i "AES128_SHA1_G2" olarak ayarlayın.
 - Phase 1 Key Lifetime'ı 86400 olarak ayarlayın.
 - Phase 2 Encryption Algorithm'i "AES128_SHA1" olarak ayarlayın.
 - Phase 2 Key Lifetime'ı 3600 olarak ayarlayın.

Advanced IKE Settings	less		
NAT_Traversal	Enable ᅌ		
Phase 1			
Mode	Main ᅌ		
Encryption Algorithm	AES - 128 ᅌ		
Integrity Algorithm	SHA1 ᅌ		
Select Diffie-Hellman Group for Key Exchange	1024bit(DH Group 2)	\diamond	
Key Life Time	86400	Seconds	
Phase 2			
Encryption Algorithm	AES - 128 ᅌ		
Integrity Algorithm	SHA1 ᅌ		
Perfect Forward Secrecy(PFS)	None	\diamond	
Key Life Time	3600	Seconds	

Dial VPN

IPsec VPN Monitor sayfasına girin ve Trigger'a tıklayın.

IPSec \	/PN					
Setup	Monitor					
	The status of IP	Sec Tunnel is displayed on this p	age. You can trigger the IPSec	Tunnel or change its status by o	licking the button in the table.	
м	onitor					
	Refresh Interval		No Refresh 😂			
s	tatus :					
	Status	Connection Name	Remote Gateway	Local Addresses	Remote Addresses	Action
		client	118.166.168.105	192.168.24.1	192.168.1.1	Trigger
	_					

VPN bağlandıktan sonra VPN durumunu görebiliriz.

The status of IPSec	Tunnel is displayed on this	page. You can trigger the IPSe	c Tunnel or change its status	by clicking the button in the table	a.
		pager ree can engger me n de	e ranner er entange no otatao		
Monitor					
Refresh Interval :		No Refresh			
Refresh Interval : Status :		No Refresh 📀			
Refresh Interval : Status : Status	Connection Name	No Refresh 🗘	Local Addresses	Remote Addresses	Action





VPN and Remote Access >> Connection Management

					ᅌ Dia	al			
PN Conr urrent P	ection Status age: 1						Page No). Go	>>
VPN	Туре	Remote IP	Virtual Network	Tx Pkts	Tx Rate(Bps)	Rx Pkts	Rx Rate(Bps)	UpTime	
1 server)	IPsec Tunnel AES-SHA1 Auth	via WAN1	192.168.24.1/24	650	4554	693	432	0:0:37	Drop
					*******	: Dat	a is encryp a isn't enc	oted. rypted.	
		9							
		2							
		7							