



IPSEC XAUTH WINDOWS'TAN VIGOR ROUTER'A

Xauth'lu IPsec tüneli yalnızca önceden paylaşılan bir key değildir ayrıca VPN client tüneli oluştururken kimlik doğrulaması için kullanıcı adı ve parola gerektirir böylece IPsec tüneli güvenliğini artırabilir. Bu makale, Vigor Router ve Windows arasında Xauth ile IPsec tünelinin nasıl oluşturulduğunu göstermektedir.

Vigor Router Kurulumu

1.	VPN and	Rem	ote Access >>	> IPsec	General	Setup	bölümüne gidin.

PN IKE/IPsec General Setup		
ial-in Set up for Remote Dial-in use	rs and Dynamic IP Client (LAN to LAN).	
IKE Authentication Method	None	
Certificate for Dial-In	None V	
General Fre-Shared Key		
Pre-Shared Key		
Confirm Pre-Shared Key		
Pre-Shared Key for XAuth Us	er	
Pre-Shared Key	•••••	
Confirm Pre-Shared Key		
IPsec Security Method		
Medium (AH)		
Data will be authenticated	, but will not be encrypted.	
	, ,,	

- 2. VPN and Remote Access >> Remote Dial-in User bölümüne gidin.
 - a. User account and Authentication 'u etkinleştirin.
 - b. IPsec Xauth dial-in türüne izin verin.
 - c. Kullanıcı adı ve şifre girin.
 - d. Kaydetmek için **OK**'a tıklayın.





	VPN and	Remote	Access	>>	Remote	Dial-in	User
--	---------	--------	--------	----	--------	---------	------

User account and Authentication	Username Password Enable Mobile One- PIN Code Secret IKE Authentication Meth Pre-Shared Key	User Time Passwords(mOTP) 	
	Digital Signature(X None ▼ IPsec Security Method ✓ Medium(AH) High(ESP) ✓ DES Local ID (optional)	3DES AES	
Subnet LAN 1 • Assign Static IP Address 0.0.0.0 Note:	_		

Windows Client Kurulumu

- 1. IPsec Xauth'u destekleyen Windows için VPN client yazılımını indirin. Burada örnek olarak **Shrew Soft VPN Client** kullanıyoruz.
- 2. VPN Access Manager'1 açın
- a. Add'e tıklayın.

Auc		/PN Ac	cess Ma	nager	_	×	
	File	Edit	View	Help			
	6		0				
	Conr	nect	Add	Modify	Delete		

b. General sekmesinde VPN Hostname or IP Address'i girin.

Dray Tek



VPN Site Configuration	×
General Client Name Resolution Authenticatic Remote Host Host Name or IP Address Port 192.168.39.236 500 Auto Configuration ike config pull	
Adapter Mode	
MTU Obtain Automatically 1380 Address . . Netmask . . .	
Save Cance	1

- c. Authentication sekmesinde Mutual PSK+XAuth'u seçin.
- d. Local identity ve Remote identity için sırayla **IP** Address ve any olarak ayarlayın.
- e. XAuth kullanıcısı için Pre-Shared Key girin.

VPN Site Configuration X	VPN Site Configuration	×	VPN Site Configuration	\times
Client Name Resolution Authentication Phase	Client Name Resolution Authentication	Phase 🔹 🕨	Authentication Phase 1 Phase 2 Policy	• •
Authentication Method Mutual PSK + XAuth V	Authentication Method Mutual PSK + XAu	th ~	Authentication Method Mutual PSK + XAuth	~
Local Identity Remote Identity Credentials	Local Identity Remote Identity Credent	als	Local Identity Remote Identity Credentials	
Identification Type	Identification Type	_	Server Certificate Autority File	_
IP Address 🗸 🗸	Any	\sim		
Address String			Client Certificate File	- 11
Use a discovered local host address			Client Private Key File	
			Pre Shared Key	
			••••	
Save Cancel	Save	Cancel	Save	ancel

- f. Phase 1 kurulumunda Cipher Algorithm bölümünü **aes** olarak ayarlayın.
- g. Phase 2 kurulumunda Transform Algorithm bölümünü esp-aes olarak ayarlayın.





Proposal Parameters		_	Proposal Parameters			
Exchange Type	main	\sim	I ransform Algorithm	esp-aes	\sim	
DH Exchange	auto	\sim	Transform Key Length	auto \sim	Bits	
Cipher Algorithm	aes	\sim	HMAC Algorithm	auto	~	
Cipher Key Length	auto 🗸 🗸 B	its	PFS Exchange	disabled	~	
Hash Algorithm	auto	\sim	Compress Algorithm	disabled	\sim	
Key Life Time limit	86400 S	ecs	Key Life Time limit	3600	Secs	
Key Life Data limit	0 K	bytes	Key Life Data limit	0	Kbytes	
TEnable Check Point C	Compatible Vendor ID					
	•					

- h. Save butonuna tıklayın.
- i. Kaydedilen VPN Client'a tıklayın ve IPsec VPN tünelini oluşturmak için içerdeki kullanıcının kullanıcı adını ve şifresini girin.

 VPN Access Manager File Edit View Help 	—	×	VPN Connect - 192.1 X Connect Network
Connect Add Modify Delete			Credentials Username Password Connect Exit

Son olarak, VPN Connect mesajı aşağıdaki gibi görünecektir.





🐼 VPN C	Connect	- 192.1	—		\times	
Connect	Network					
local id o remote is pre-shar bringing network tunnel e	configure d configu ed key ci up tunne device c nabled	d red onfigured I onfigured			^	
Creder	ntials					
Usern	ame us	er				
Passy	vord					
		Disconne	ct	Cance	el	

Ve Vigor Router'ın VPN durumunu VPN and Remote Access >> Connection Management sayfasından görebilirsiniz.

VPN Cor	nnection S	tatus									
All VPN Status LAN-to-LAN VPN Status					Remote D	ial-in l	Jser Status				
VPN	Туре	9	Remote IP	Virtua	l Network	Tx Pkts	Tx Rate(bps)	Rx Pkts	Rx Rate(bps)	UpTime	
1 (user)	IPsec Tur AES-MD5 /	inel 19 Auth	2.168.39.232 via WAN2	192.10	58.1.26/32	3096	32	1423	48	0:9:54	Drop