

EAP600'de Bant Yönlendirme Özelliği Var mı?

EAP600, bant yönlendirme özelliği olmadan piyasaya sürüldü. Bant yönlendirme desteği, donanım yazılımı sürümü 1.3.7 ile başlamıştır ve ayrıca en son 1.5.2 donanım yazılımında da desteklenmektedir. Bant yönlendirmeyi etkinleştirmek için GUI'ye erişin ve "Sistem" altındaki "Band Steer" seçeneğine gidin, ardından "Etkinleştir"i seçin.

The screenshot displays the EnGenius web interface for a Wireless Access Point/Client Bridge. The page title is "Band Steering" and it includes "Home" and "Reset" buttons. A note states: "In order for Band Steering function to work properly, both 2.4GHz and 5GHz SSID and Security Settings must be the same." Below the note, the "Enable" checkbox is checked, and there are "Accept" and "Cancel" buttons. The left sidebar shows the navigation menu with "Band Steer" highlighted under the "System" section.

EnGenius® | **Wireless Access Point/Client Bridge** English

AP/AP

Status

- Save/Reload:0
- Main
- 2.4G Wireless Client List
- 5G Wireless Client List
- System Log

System

- Operation Mode
- IP Settings
- Spanning Tree Settings
- Band Steer

2.4G Wireless

- Wireless Network
- Wireless MAC Filter
- Wireless Advanced Settings
- WPS

Band Steering Home Reset

NOTE:

In order for Band Steering function to work properly, both 2.4GHz and 5GHz SSID and Security Settings must be the same.

Enable

Accept Cancel